

PURCHASED  
28-JAN 1967

HOME RAD 2


**NOMBREX**

WIDE RANGE TRANSISTORIZED

# SIGNAL GENERATOR

MODEL 27

## OPERATING INSTRUCTIONS



Manufactured by

**NOMBREX LTD.** (INSTRUMENTS  
DIVISION)

ESTUARY HOUSE, CAMPERDOWN TERRACE  
EXMOUTH - DEVON - ENGLAND

Tel.: Exmouth 3515

'Grams : Nombrex, Exmouth.

The **MODEL 27** Generator was designed to meet the need for a small and really portable instrument at a competitive price. Although of simple construction and operation it is capable of performance comparable with other more expensive instruments. It is of robust construction, employing the latest techniques of design and assembly, and with normal use will stand up to continuous hard use with complete reliability.

#### CIRCUIT

The circuit design employs an R.F. transistor signal oscillator, the circuit characteristics being carefully chosen to ensure stable operation under varying conditions and temperatures. The R.F. signal is available either unmodulated, or alternatively modulated by a 400 cycles sine wave from a separate A.F. Modulator transistor. Printed circuit assembly is employed for stability and long-term reliability.

#### RANGES:

The instrument gives continuous frequency coverage from 150 Kc/s to 350 Mc/s, in eight bands as below:—

(1) 149 Kc/s	To 438 Kc/s	(5) 9.8 Mc/s	To 34.1 Mc/s
(2) 425 Kc/s	To 1.25 Mc/s	(6) 29.5 Mc/s	To 69.0 Mc/s
(3) 1.18 Mc/s	To 3.83 Mc/s	(7) 56.0 Mc/s	To 166.0 Mc/s
(4) 3.4 Mc/s	To 10.75 Mc/s	(8) 118.0 Mc/s	To 350 Mc/s

All signal ranges except No. 8 are on fundamentals

#### GENERAL SPECIFICATION

**ACCURACY:** Better than  $\pm 2$  per cent. overall, but generally within  $\frac{1}{2}$  per cent. to  $1\frac{1}{2}$  per cent. on individual ranges and scale positions.

Frequency shift with change of load or attenuator setting generally less than .2 per cent. Shift due to failing battery voltage less than .4 per cent. down to 7.5V at which voltage battery should be renewed.

**OUTPUT LEVEL:** Average 50 mV into 75 ohms load on all ranges, dependent on range and frequency: A.F. output approximately 1 Volt R.M.S. at 400 c/s.

**OUTPUT IMPEDANCE:** Employing of necessity a miniature resistive attenuator the output impedance varies with attenuator setting, and is 400 ohms at maximum. Both R.F. and A.F. output sockets are D.C. isolated by capacitors rated 500 V DCW. If the signal is to be applied to test points at a higher potential than 500V, an additional capacitor of suitable voltage rating should be inserted at the red "live" lead termination of the test lead. The black lead clip is normally connected direct to the chassis of the receiver. The output attenuator does not operate on the A.F. output.

**BATTERY:** Employs standard 9 volt transistor battery, Ever-Ready PP4, Drydex DT4, or equivalent. Suitable U.S.A. or Continental alternative types are available in all overseas territories.

**CONSUMPTION:** Total 3mA (average) giving several months' of battery life with normal usage. The battery should be replaced when it has fallen to the 7.5V minimum. Be sure to switch the instrument to "OFF" position when not in use to conserve battery. Run-down batteries, if left in the instrument, may leak and cause irreparable damage.

#### CONTROLS:

**FREQUENCY CONTROL:** Transparent hair-line cursor permitting adjustment to 1 per cent. accuracy. All ranges are directly calibrated.

**FUNCTION SWITCH:** Four-position switch, providing unmodulated R.F., modulated R.F., A.F. sine wave only (at separate socket), and switch-off.

**RANGE SWITCH:** Eight-position switch, numbered to correspond with the ranges of the frequency scale.

**ATTENUATOR:** Operates on the R.F. Signal only, and is arbitrarily divided into ten un-calibrated divisions.

#### **ACCESS**

Instruments are supplied without battery fitted, to avoid deterioration. Access to fit or renew battery is by removing the eight rear screws and back cover. Ensure that the battery is firmly gripped in the spring clip provided and that the connectors are clear of any components.

#### **OPERATION**

It is not considered necessary to give detailed instruction in the use of R.F. Signal Generators as most users will already be familiar with the procedure, and the subject is adequately covered by a number of standard textbooks. The following, however, is a brief resume of the general procedure for testing and alignment of radio receivers or amplifiers.

- A. The audio-frequency signal from the generator may be used for general testing and fault-finding in the A.F. and output stages of radio receivers, the last stages of sound channels of T.V. receivers, and for audio amplifiers or record players. The normal procedure is followed, applying the A.F. signal to successive audio stages, working backwards from the output stage. Quantitative or comparative stage gain measurements can be taken if an A.F. output meter is used at the receiver or amplifier output terminals.
- B. The I.F. amplifiers of both radio and T.V. receivers may be tested and accurately aligned in a similar manner, with the generator function switch set to MOD.
- C. The oscillator or frequency-changer circuits of radio or T.V. receivers may be similarly tested or aligned, applying a generator signal to the aerial input terminal. In the case of radio receivers, this follows the usual method of setting the receiver tuning to a calibration mark near the low frequency end of the scale, adjusting the generator to the correct frequency and adjust for maximum response on the oscillator and aerial input inductors. To obtain correct tracking over the waveband the same procedure is followed at a setting on the receiver scale near to the high-frequency end of the scale, the oscillator and aerial capacitance trimmers being adjusted for resonance. The above procedure should then be repeated at the low and high frequency points until completely in resonance. At all times testing should be carried out with the generator signal attenuated to the minimum possible, to avoid either overloading of the A.F. stages or false tuning resonances due to the AGC circuits operating.


#### **GUARANTEE:**

The Model 27 Signal Generator is Guaranteed for a period of twelve months from purchase date against any defect or faulty manufacture, provided that the instrument has not been damaged by mis-use, has not been adjusted or serviced by anyone other than the manufacturers' service department or their appointed agent in U.K. or overseas.

#### **SERVICE:**

If the instrument should require service, unless otherwise arranged it should be returned, if purchased in U.K., to the Service Department of the manufacturer, or if purchased outside U.K. to the supplier from whom the instrument was purchased. It should be adequately packed, mailing charges pre-paid, and be accompanied by a letter clearly specifying the nature of the complaint.

RA model to 68K AF tune wale 75K



# SIGNAL GENERATOR 27. PARTS LIST

Key	Value	Tol.	Part No.
R1	3.3K	10%	21
R2	560 ohms	10%	20
R3	18K	10%	24
R4	390 ohms	10%	19
R5	400 ohms	10%	5
R6	560 ohms	10%	20
R7	12K	10%	23
R8	6.8K	10%	22
R9	150K	10%	25
C1	.003uF	25%	51
C2	.01uF	25%	49
C3	.0047uF	25%	50
C4	.01	25%	40
C5	220pF	20%	53
C6/7	228+65pF	1%	3
C8	10pF	10%	56
C9	500pF	20%	55
C10	.001uF	20%	54
C11	.001uF	20%	54
TR.1	R.F. Transistor	—	12
TR.2	A.F. Transistor	—	16

Part No.	Value
10	A.F. Transformer
2	Range Switch
1	Function Switch
41	Range 1 Coil
42	" 2 "
43	" 3 "
44	" 4 "
45	" 5 "
46	" 6 "
47	" 7 "
48	" 8 "
7	Case and Backplate
9	Case Handle
8	Battery Clip
13	Battery Connectors
39	Tuning Cursor Knob
14	Control Knobs
11	Output Sockets
40	Test Lead
15	Co-Axial Plug
18	Ferrite Screw Cores

17 88  
 18 88  
 19 88  
 20 88  
 21 88  
 22 88  
 23 88  
 24 88  
 25 88  
 26 88  
 27 88  
 28 88  
 29 88  
 30 88  
 31 88  
 32 88  
 33 88  
 34 88  
 35 88  
 36 88  
 37 88  
 38 88  
 39 88  
 40 88  
 41 88  
 42 88  
 43 88  
 44 88  
 45 88  
 46 88  
 47 88  
 48 88  
 49 88  
 50 88  
 51 88  
 52 88  
 53 88  
 54 88  
 55 88  
 56 88  
 57 88  
 58 88  
 59 88  
 60 88  
 61 88  
 62 88  
 63 88  
 64 88  
 65 88  
 66 88  
 67 88  
 68 88  
 69 88  
 70 88  
 71 88  
 72 88  
 73 88  
 74 88  
 75 88  
 76 88  
 77 88  
 78 88  
 79 88  
 80 88  
 81 88  
 82 88  
 83 88  
 84 88  
 85 88  
 86 88  
 87 88  
 88 88  
 89 88  
 90 88  
 91 88  
 92 88  
 93 88  
 94 88  
 95 88  
 96 88  
 97 88  
 98 88  
 99 88  
 100 88

DC 171  
 25371